

COVID-19 ULTRASOUND WORKFLOW



1

Bring the portable ultrasound outside of patients room. Have the machine logged on and ready to scan prior to entering patient room. Bring one cleaning wipe (gray or purple topped) with you.



2

Don PPE as directed by hospital policies.



3

Enter room and perform POCUS.



4

Before leaving room, wipe down ultrasound in full PPE, taking care to remove gel and other visible fluids or contamination. Place device on counter (at least 6 feet from patient, if possible).



5

Doff gown, sanitize hands, put on new gloves. Keep your mask and eye shield on.



6

Take ultrasound out of room, wipe entire unit/cord and mobile device with cleaning wipe (gray or purple topped) until they have been wet for 2 minutes, allow to air dry.



7

Remove gloves, sanitize hands, and remove other PPE as indicated.



8

Return to ultrasound storage clean tray/space to dry and be used by next provider.

